CNC machines

What setup do I need if I want to create P-System grooves with my CNC machine?



