

Lamello Drawer Box Construction with Cabineo and Mozaik Software



"With Cabineo we can offer a strong and durable product at a good price for our customers. Any additional cost of the cabineo is offset by speed of assembly with no exposed fasteners. The quality of the fasteners also means no call backs."

Andy Sutherlin, Flawless CNC, Fort Worth, TX



"Using Cabineo for drawer boxes was such an improvement over Confirmat screws that it made my installer cry."



Ahmet Kaplan, CWA Cabinets- Norcross, GA

How it works:



Current Mozaik subscribers can navigate to library\hardware\fastener\joint template and choose Cabineo connector-flush cover. Then choose parameters in drawer box.



Rout or drill the Cabineo pocket to correct depth and rout additional shoulder for flush-mount installation.



Assemble the back of drawer box.





parameters are set correctly for box

construction and make adjustments



Install Cabineo connectors into pockets. Use mallet if necessary.



Finish by assembling front of drawer box.



Set the size of drawers with those parameters and input drawer box sizes.



Assemble bottom of drawer into dado first and put side of drawer on next. Turn the clutch down on drill drivers. Using an impact driver is not advised!



Completed box.



Lamello Cabineo connectors & accessories



Art. No.

186380

186381

186382

186384

186386

186350

186351



Cabineo 8	Qty.	Art. No.
(White) For center panels	500	186310
includes ball tip driver	2000	186311
(Black) For center panels	500	186340
includes ball tip driver	2000	186341



Cabineo 12	Qty.	Art. No.
(White) For corner connections	500	186320
includes ball tip driver	2000	186321
(Black) For corner connections	500	186330
includes ball tip driver	2000	186331



Cabineo 8 M6	Qty.	Art. No.
(White)	500	186315
includes ball tip driver	2000	186316
(Black)	500	186345
ncludes ball tip driver	2000	186346




Cabineo Insert Nut	Qty.	Art. No.
M6 x 12.3mm* for material 14-16mm	100	186370
M6 x 15.3mm* for material 17-25mm	100	186375
M6 x 12.3mm* for material 14-16mm	500	186371
M6 x 15.3mm* for material 17-25mm	500	186376

includes installation tool



Cabineo Accessories	Art. No.
Cabineo 4mm magnetic hex drive tool with handle	256300
Cabieno 4mm magnetic hex driver- fits traditional drill chucks and tool handle	276312
80mm long Cabineo driver bit	276308
4mm hex drive tool - 100 pack	276309
Cabineo 8 M6 installation tool	276310





Cabineo X*	Qty.	Art. No
(White)	500	186360
(vviiite)	2000	186361
(Black)	500	186365
(DIACK)	2000	186366

Qty.

500


2000

500

500







bit item 276308

Cabineo X Screws



03111111		
Cabineo X shelf support 03mm	500	186388
Cabineo X screw-in aid, works with Cabineo driver	500	276313



	Cabineo Cover Caps*	Art. No
100 Pieces	Signal White (S) Pure White (W) Fawn Brown (R) Brown Beige (B) Window Grey (F) Ivory (H) Papyrus White (P) Dark Grey (A) Black (T)	186350
2000 Pieces	Signal White (S)	186351

00 Pieces	Signal White (S)
	Pure White (W)
	Fawn Brown (R)
	Brown Beige (B)
	Window Grey (F)
	Ivory (H)
	Papyrus White (P)
	Dark Grey (A)
	Black (T)

	()
00 Pieces	Silver (C)
	Nickel (N)
	Dark Steel (I

2000 Pieces	Silver (C)
	Nickel (N)
	Dark Steel (D)
	* Juhan and

r		please mention the letter
	associated with	the color after the part number

