



MASSACHUSETTS

122 Pembroke Street, P.O. Box A, Kingston, MA 02364  
(781) 585-4364

Fax (781) 585-9375

CALIFORNIA

845 Milliken Avenue, Suite F, Ontario, CA 91761  
(909) 390-5465

Fax (909) 390-5470

### Tracking (Healing) Adjustment on Striebig Compact

1. For the vertical healing adjustment (position # E), loosen nut on nylon take-up screw (position #92) and back screw off a couple of turns. This is accessed from inside the housing with the riving knife pulled all the way back.
2. Make parallel guide adjustment by loosening the lock nuts and making equal adjustment turns on the two screws in the black plastic guide block (position # 91). Make sure the block is parallel and runs flat against the plated guide bar then tighten lock nuts and test.
3. When the guide block is set, turn the nylon take-up screw until it just touches the parallel guide bar; lightly tighten lock nut while holding screw in position. If it creates a drag while plunging the saw head, back it off very slightly and lightly retighten the lock nut.
4. Adjust the dampener bolt (position # 90), if necessary, so that it creates a slight bit of drag as you move the saw head in and out. It should be enough so that the saw head won't "fall in" on its own, but it should not be out so much that it makes it difficult to plunge the saw head.
5. The horizontal adjustment procedure is the same as the vertical except the location is position # F.

Sägeaggregat

