



Tips tricks

90° mitre as a finish for claddings



Finish wall claddings with a mitre instead of an edge for greater aesthetics.

How it works:



1. Mill P-System grooves with depth setting 10 into the cutting surfaces



2. Insert TensoP-10 connector half into the workpieces



3. Preload connector and apply adhesive



4. Join together workpieces and wait until adhesive has hardened




5. Plane protruding points flush depending on the assembly situation



6. Install cladding

P-System

Form-locking anchorage
without tools




Tips  tricks
Find the right P-System connector
with the configurator




Clamex P


Detachable connecting fitting




Detachable




Aesthetic



High clamping
force




Stackable




Versatile

Tenso P


with preload clip, self-clamping fitting as
glueing aid, for all angles




Glueing




Invisible



High clamping
force




Versatile




Lower assembly
force

Divario P


Self-clamping, invisible fitting for slide insertion




Sliding insertion




Invisible



Clamped joint



Fast installation



Assemble by sliding



Manufacturer:
Lamello AG
Joining technology
Hauptstrasse 149
CH-4416 Bubendorf
Tel. +41 61 935 36 36
Fax +41 61 935 36 06
info@lamello.com
www.lamello.com